




	EB-1900	EB-1830	EB-1910	EB-1920W	EB-1915	EB-1925W
<b>Lúmenes</b>	4000	3500	4000	4000	4000	4000
<b>Resolución</b>	XGA	XGA	XGA	WXGA	XGA	WXGA
<b>Ordenador In</b>						
<b>Vídeo</b>	1	2	2	2	2	2
<b>Audio</b>	No	2	2	2	2	2
<b>Monitor Out</b>						
<b>Vídeo</b>	No	1	1	1	1	1
<b>Audio</b>	No	1	1	1	1	1
<b>Altavoz</b>	No	10W	10W	10W	10W	10W
<b>Keystone</b>						
<b>V</b>	Manual	Auto	Auto	Auto	Auto	Auto
<b>H</b>	No	No	No	No	Auto	Auto
<b>Screenfit</b>	No	No	No	No	Si	Si
<b>Autofocus</b>	No	No	No	No	Si	Si
<b>HDMI</b>	No	No	No	No	Si	Si
<b>RJ-45</b>	No	Si	Si	Si	Si	Si
<b>Wi-Fi</b>	No	No	No	No	Si	Si
<b>Funciones LAN</b>	---	EasyMP Monitor EasyMP Network Proj. No Audio	EasyMP Monitor EasyMP Network Proj. No Audio	EasyMP Monitor EasyMP Network Proj. No Audio	EasyMP Monitor EasyMP Network Proj.	EasyMP Monitor EasyMP Network Proj.
<b>USB-A</b>	No	1	1	1	2	2
<b>Funciones USB-A</b>	---	Slide Show	Slide Show	Slide Show	PC Free Quick Wireless Setup	PC Free Quick Wireless Setup
<b>USB-B</b>	Si	Si	Si	Si	Si	Si
<b>Funciones USB-B</b>	USB Display (2 en 1) Mouse Teclado Control	USB Display (2 en 1) Mouse Teclado Control	USB Display (2 en 1) Mouse Teclado Control	USB Display (2 en 1) Mouse Teclado Control	USB Display (3 en 1) Mouse Teclado Control	USB Display (3 en 1) Mouse Teclado Control
<b>Cámara documentos</b>	No	Opcional	Opcional	Opcional	Opcional	Opcional
<b>Quick Wireless Key</b>	No	No	No	No	Opcional	Opcional



- |                      |                     |
|----------------------|---------------------|
| 1 - Video Input      | 9 - Audio Input 2   |
| 2 - S-Video          | 10 - USB (Type B)   |
| 3 - Video-L Input    | 11 - LAN            |
| 4 - Video-R Input    | 12 - Monitor Out    |
| 5 - RS-232C          | 13 - Audio Out      |
| 6 - Computer Input 1 | 14 - USB (Type A) 1 |
| 7 - Audio Input 1    | 15 - USB (Type A) 2 |
| 8 - Computer Input 2 | 16 - HDMI           |